Measurement Value

This instrument displays the concentration of ethanol in water as a percentage of total volume.

When a solution contains components other than ethanol and water, the readings may not correspond to alcohol by volume.

This instrument is designed to estimate the approximate alcohol content of distilled beverages/spirits.

Automatic Temperature Compensation

The readings are corrected, based on the temperature of the prism, within the automatic temperature compensation range.

Measurements may fluctuate with hot or cold samples. Wait for approximately 20 seconds to press the START button. Measurements will stabilize once the instrument acclimates to the sample temperature.

Storage and Maintenance



Store the instrument in a dry place away from direct sunlight. Exposure to humidity and heat may damage the instrument.



Clean and dry the sample stage thoroughly, following the "Cleaning" instructions. Store the unit away from direct sunlight at a stable temperature with as little fluctuation as possible.

Repair and Warranty

The instrument is warranted for one year from the date of purchase. This warranty is void if the instrument shows evidence of the following. Send the included batteries as well if they are still in use.

- Having been disassembled by unauthorized personnel Having been misused and/or operated outside the environmental specifications
- Damages to the prism and/or sample stage
- Leakage from batteries other than those included with the unit
- · Water damage or having been dropped

Repair services are available for a fee after the warranty expires.

Contact an ATAGO authorized service center for service and support.

Please have the serial number information ready when contacting a service center.

	S	pecifications	
Measurement range	Ethyl alcohol 0.0 to 53.0% (mL/100mL) 5.0 to 30.0°C	Maximum number of data history	100
Resolution	0.5% / 0.1°C	Output	NFC Forum Type 4 Tag
Accuracy	±1.0% / ±1°C	_	ISO/IEC 14443 Type A
Automatic temperature	5 to 30°C	_	Output category : Date Time,
compensation range			Ethyl alcohol [mL/100mL], Temp [degC]
Ambient temperature	10 to 30°C	_	(e.g.) 2017/08/17 09:30:45, 12.0, 20.4
range		Power supply	Two (2) AAA alkaline batteries
Sample volume	At least 0.3mL	Battery life	Approx. 11,000 measurements
Measurement time	Approx. 3 seconds	_	(when using alkaline batteries)
Backlight	The backlight stays on for 30 seconds	International	IP65
	after any button is pressed.	Protection class	
		Dimensions and weight	55 (W) x 31 (D) x 109 (H)mm, 100g (main unit only)

The product is in conformity with the requirements of the EMC Directive 2004/108/EC. Patent Granted in Japan, United States, Germany, China and Taiwan.

ATAGO CO.,LTD.

Headquarters: The Front Tower Shiba Koen, 23rd Floor 2-6-3 Shiba-koen, Minato-ku, Tokvo 105-0011, Japan TEL: 81-3-3431-1943 overseas@atago.net http://www.atago.net/

ATAGO U.S.A., Inc. TEL: 1-425-637-2107 customerservice@atago-usa.com

ATAGO INDIA Instruments Pvt. Ltd. TEL: 91-22-2854-4915 / 4071-3232 customerservice@atago-india.com

ATAGO THAILAND Co.,Ltd. TEL: 66-21948727-9 ,66-21171549 customerservice@atago-thailand.com

ATAGO BRASIL Ltda.

TEL: 55 16 3913-8400 customerservice@atago-brasil.com ATAGO ITALIA s.r.i. TEL: 39 02 36557267 customerservice@atago-italia.com

ATAGO NIGERIA Scientific Co., Ltd. TEL: 234-707-558-1552 atagonigeria@atago.net **E**ATAGO KAZAKHSTAN Ltd. TEL: 7-727-257-08-95

ATAGO RUSSIA Ltd.

TEL: 86-20-38108256

info@atago-china.com

TEL: 7-812-777-96-96

info@atago-russia.com

info@atago-kazakhstan.com

ATAGO CHINA Guangzhou Co.,Ltd.

2107K Printed in Japan

4433-E21

Digital Hand-held "Pocket" Ethyl alcohol Refractometer

PAL-33S Cat.No.4433



Parts

The warranty period extension method 1 year → 2 years

The warranty period will be extended from 1 year to 2 years when you register customer information. QR code

ATAGO Logger NFC can also be downloaded at the same

Trouble scanning the code? Access https://www.atago.net/ur/ index.php?l=en

LCD

Measurement results, prism temperature. remaining battery charge, etc., are displayed. The displayed value is an example.

START button (POWER button)

Press to take measurements and hold down to turn off the display.

Batterv compartment

Place and remove batteries from here.

Sample stage

Apply water and samples on the glass prism located in the center of the sample

ZERO button

Press to perform zero-setting.

START button & ZERO button

Press to set date, time. and delete data history.

Lanvard hole

Image is for explanation purposes only. It may be different than the actual product purchased.

Contents

Pocket

AAA alkaline batteries are included. Remove the tape from the battery compartment before inserting the batteries.

ATAGO instruments are rigorously inspected to ensure each unit meets the highest standards of quality assurance.

Introduction

Thank you for purchasing the instrument. Carefully read and follow all instructions. Keep this manual for future reference.

Safety Instructions

Read and follow all safety instructions before operating the instrument. Failure to comply with the following instructions may result in personal injury or property damage.

♠ WARNING

- Ensure safety when handling hazardous materials. Observe precautionary measures and use protective equipment. Be aware of the hazards of such chemicals and emergency response guidelines.
- ATAGO may not be held liable for any injury or damage arising in connection with handling of hazardous materials during the use of the instrument.
- ♦ Do not drop the instrument or subject it to strong physical shock.
- Do not attempt to repair, modify, or disassemble the instrument.

∴ CAUTION

- Carefully read this manual to have basic knowledge of the function of each component.
- ATAGO is not liable for any loss and damage caused by the measurement and use of this instrument.
- Some acids may corrode the glass prism and/or metal sample stage, which may cause erroneous measurements.
- ♦ Do not use metal tools, such as a spoon, as they may scratch the prism, resulting in erroneous measurements.
- ♦ Do not use water above 50°C to rinse the instrument.
- Only use the specified battery type. Observe proper polarities, properly aligning the anodes and cathodes.
- ♦ Store the instrument away from direct sunlight/heat sources and excessive amounts of dust/debris.
- ♦ Do not expose the instrument to a rapid change in ambient temperature.
- ♦ Do not subject the instrument to strong vibration.
- Do not subject the instrument to extreme cold temperature.
- ♦ Do not place the instrument under anything heavy.
- ♦ Loosen the battery compartment cover for air transportation.

⟨International Protection Classification IP65⟩

♦ The instrument is water-resistant, not waterproof, and should not be submerged.

<Chemical Resistance of Body Case>


♦ The body case is made of resin. Do not expose it to water vapor. Some solvents may compromise the structural integrity of the instrument.

Zero-setting and Measurement

Zero-setting

[Caution]


- ♦ Zero-set the instrument at the beginning of each day before use as well as after replacing the batteries.
- ♦ Let water on the prism acclimate to the temperature of the instrument before zero-setting.
- ♦ When "AAA" is displayed, wipe the prism clean, apply water, and press the ZERO button again.



Measurement

[Caution]

- ♦ Do not use metal tools to apply samples on the prism as they may scratch the prism.
- ♦ Initial measurements may fluctuate with hot or cold samples. Wait for the instrument to acclimate to the sample temperature, approximately 20 seconds, to press the START button. Alternatively, press the START button multiple times until measurements become stable
- ♦ Do not splash water above 50°C. The plastic may warp, which may compromise the water resistance.
- When measuring hot samples, place only the necessary amount and do not let it overflow from the sample stage well.
- When hot water is necessary to clean off hardened samples, use water-soaked gauze around the prism area and keep hot water away from the body case.
- ♦ The displayed temperature is that of the prism and may not necessarily match the temperature of the sample.



<LCD Auto Shut-off>

The instrument will turn itself off after 2 minutes of inactivity. To manually turn it off, hold down the START button for more than 2 seconds.

<For oilv/fattv samples>

Try stirring the sample on the prism while measuring to improve the repeatability of oily/fatty samples.



Cleaning

[Caution]

- On not scratch the prism.
- ♦ The instrument is water-resistant, not waterproof, and should not be submerged.
- 1. Wipe off the sample.
- 2. Clean the prism and sample stage using a mild soap and thoroughly rinse with water.
- 3. Dry the area with tissues thoroughly.





Error Messages


The following messages alert the user when an operation has failed

LO.

The battery is low.



The ZERO button was pressed with nothing or something other than water on the prism.



The sample measured outside the measurement HHH range.



Too much light is entering the prism, and the nnn instrument cannot measure accurately.

(Shade the sample stage with your hand and take a measurement again.)

range.

The prism temperature is below the temperature



The prism temperature is above the temperature range.





The instrument is faulty. (Replace the batteries, Contact ATAGO if this



[Caution]

- \$\triangle\$ Fasten the battery compartment cover tightly to prevent water ingress or poor connection, which will cause erroneous measurements. Push the cover in firmly and turn.
- ♦ When the O-ring on the cover is dirty or damaged, the water resistance may be compromised. (Figure 1)
- ♦ When the battery icon indicates the low power level (), replace both batteries with a brand new set of AAA alkaline batteries (1.5V).
- Static images may occasionally appear on LCD. Such retained pixel charges do not indicate a faulty display, consume the battery power, or affect the instrument's performance in any way.
- ♦ Check the expiration dates on batteries before purchase.
- ♦ Zero-set the instrument after the batteries are replaced.





4. Close the battery compartment cover by pushing the cover in with a coin in the groove and turning it clockwise until it stops.

Figure 1

Furning excessively may cause malfunction.

