



KERN & Sohn GmbH

Ziegelei 1

D-72336 Balingen

E-Mail: info@kern-sohn.com

Tel: +49-[0]7433- 9933-0

Fax: +49-[0]7433-9933-149

Internet: www.kern-sohn.com

Operating Instructions KERN EasyTouch

EasyTouch Count User manual

Version 1.1

2022-09

GB




Contents

1.0	Introduction to count	3
2.0	Device features	4
2.1	Device details	5
2.2	Net value	5
2.3	Tare	6
2.3.1	Auto tare	6
2.3.2	Manual tare	6
2.3.3	Delete tare value	7
2.4	Zero	7
2.5	Stability	8
2.6	Min and max	8
2.7	Net indicator	9
2.8	Unit change	9
3.	Functional features	10
3.1	Defining the reference weight	10
3.1.1	Manual	10
3.1.2	Auto	12
3.2	Defining the quantity of reference object	16
3.3	Reset	18
3.4	Memory	19
4.	Auto save	23
4.1	Auto save semi	23
4.2	Auto save full	25
5.	Result data	27
5.1	Measurement data	27
5.1.1	Add object from memory	27
5.1.2	PDF, print and save	27
5.1.3	Dynamic object ID and name	28
5.1.4	Update object in master memory	28
5.1.5	Auto print	28
6.	Dynamic data	28


1.0 Introduction to count

This function offers the possibility to determine the piece quantity of several items, referring to a previously defined reference weight.


- Click on the function menu from the main menu.



- The function list screen will open. Click on the count function from the function list.




- The main screen of the function appears,




2.0 Device features

The device features can be utilized upon connecting the device with the weighing scale.




- Indication of “no device being connected” will be displayed.
- The functional features will be displayed in the right-hand side of the screen
- The provision to minimize and maximize were also being given in the upper right corner of the screen to get a full view mode
- Now connect a device to proceed with weighing of an object by clicking on the “Connect a device to continue”
- Connect a device which is physically connected to the system and now the weighing mode is activated, and screen looks as per the below.




2.1 Device details

The system will display the prominent details of the device as such internal code, model name, min, max, d and e value (in case of verified weighing scale) once the device is connected.



2.2 Net value

The weight on the scale would be displayed with the default unit in gram.




2.3 Tare:

User can utilize the tare in two ways


2.3.1 Auto tare

Place weight on the scale and press the tare button. The weight on the scale would tare.




2.3.2 Manual tare

Click on the hyperlink against the tare and enter the tare value.



2.3.3 Delete tare value


- Click on the clear to delete the tare value manually or remove the weight on the scale and click on the zero button.
- Kindly note, the zero works only when the weight on the scale is less than 2.5 % of the max value of the device.



2.4 Zero


The Zero is used to remove the unwanted weight from dust, rust, or other build ups. This is used when there is nothing on the scale, but the reading doesn't display Zero.

- The expected is to set the weight measurement starting from zero.
- The zero will be indicated by the Zero indicator.




2.5 Stability

The stable indicator will be displayed once the weight on the scale gets stabilized.




2.6 Min and max

The minimum and maximum value that the device can hold will be displayed under the progress bar




2.7 Net indicator

The net indicator would be displayed in case of tare is being set.




2.8 Unit change

- User has been offered with some of the frequently used units by default units. This can be accessed by clicking on the unit on the weighing screen.



- By accessing the unit, the user gets this screen to swap the unit in case if required. The respective unit can be accessed by the click.



3. Functional features


The start screen for this function appears,

3.1 Defining the reference weight


There are two ways to define the reference weight via manually and automatic.

3.1.1 Manual


- Click on the “define reference weight” to set the reference weight
- The below screen appears




- Choose the mode as “manual” and enter the reference weight, quantity of reference objects and the respective unit.
- Save the entry with the button “apply” below right. The reference weight is now determined and is displayed.



- When using the tare, place the respective object and click on tare button or click on the tare button or enter the tare weight manually.
- The tare weight and net count is displayed with the indicator “NET”
- Now, place the required object on the weighing plate.




- The result quantity of the objects would be calculated and displayed in alignment with the set reference weight and quantity if objects.
- The net weight along with the reference weight would be displayed in the screen for user's reference.
- Click on the result button to proceed in saving the data.




3.1.2 Auto


- Reset the process before defining the reference weight of the object automatically by clicking on reset.




- Choose the mode as “auto” and the below screen appears.




- Place the object or weight in the weighing machine which is required to be taken as a reference weight for the objects that are going to be measured.




- The system would offer the default units while measuring as such gram, kilogram, carat, ounces and pound.




- Wait for the stability display and click on the “set reference weight” button.
- Choose the respective unit and set the reference quantity



- When using the tare, place the respective object and click on tare button or click on the tare button or enter the tare weight manually.
- The tare weight and net count is displayed with the indicator “NET”




- Now, place the required object on the weighing plate.
- The result quantity of the objects would be calculated and displayed in alignment with the set reference weight and the net weight placed on the scale.
- The net weight along with the reference weight would be displayed in the screen for user's reference.
- Click on the result button to proceed in saving the data.




3.2 Defining the quantity of reference object


- Place a reference weight on the scale which shall correspond to 5 quantity and press "weight = 5 pcs" button.




- The piece quantity is displayed. The reference weight per piece will be calculated automatically and weight is displayed.




- The reference weight for 10, 20, 50 and 100 can also be determined by clicking on the icons “weight = 10 pcs”, “weight = 20 pcs”, “weight = 50 pcs” and “weight = 100 pcs” respectively.



- In addition, the user can allocate a self-defined weight to a self-defined quantity of items.




- Place the reference object on the scale and enter the quantity which shall match with this weight.
- The reference weight per piece would be calculated automatically and displayed to the user.
- The user can click on the “apply” button to set the reference weight.




- Now place the weight to which the count must be calculated. The count will be calculated based on the reference weight and would be displayed accordingly

3.3 Reset

- The purpose of reset is to clear the stored readings.



- Upon clicking the reset, system will reset all the weighed data, applied master data and will be ready to perform the new operation




3.4 Memory


The user might be able to pick an object from the memory where the user can predefine list of objects what you use frequently. The object in the memory can be reutilized.

[Steps to be followed to create a master data with functional properties](#)

- Click on the database icon and redirect to the master data.
- The below screen would be displayed. The user might be able to see the list of master data objects created here.



- The user can click on the “add master object” to create a new master object.



- The user can fill in the information as such component / object ID, Component / object name, ID number / name, description, container weight and the image for the reference.

Master Database
Database > New master data

English admin Admin...

New master data

Remove image
Only .jpg, .png & .bmp

Component / Object ID number *
E656778

Component / Object name *
Eggs

ID number / Name
8767382 / Eggs

Description
Eggs from Mexico

Container weight
56

unit
g

Assign functions
Please select the object type

Select all Clear all Close

Search

☐ Formulation component

☐ Variable

☐ Dynamic

☒ Count

☐ Batch & Statistics

Back Submit

- Now user can select the required function “count” to utilize the properties.
- Upon clicking the function, the functional properties as such reference weight and reference count would be displayed
- User can enter the respective values and choose the respective units and click on submit to save the master object.

Master Database
Database > New master data

English admin Admin...

New master data

Remove image
Only .jpg, .png & .bmp

Component / Object ID number *
E656778

Component / Object name *
Eggs

ID number / Name
8767382 / Eggs

Description
Eggs from Mexico

Container weight
56

unit
g

Assign functions
Count

Count


Reference weight *
100

Unit
g

Quantity of reference objects *
100


Back Submit

- The master object data is being saved and user could be able to view the created master object in the master list.




Utilize the master data in the function


- Now redirect to the function “count” to utilize the created master data
- Click on the memory and the user will be taken to the master memory to pick from the list of objects predefined. User can click on the required object to be weighed.



- User will be provided with the search option to search the required weighing object.



- User will be redirected to the weighing screen upon clicking the required object.
- The master object would be added here, and the respective reference weight and count defined will also be reflecting in the function upon applying the master data with the defined count properties.



4. Auto save


4.1 Auto save semi

- The purpose of auto save semi is to avoid pressing the result button once the measurement is done.
- The user will be automatically redirected to the result screen upon loading and unloading of the weight (until reaching zero) and stabilization of the object placed on the weighing scale.

- This might be useful in reducing the work of operators as they might not need to press the result button every time.


Steps to be followed:

Step 1: Enable auto save semi after defining the reference weight



Step 2: Place the objects that are required to be counted

Step 3: Wait until the weight on the scale is stabilized



Step 4: The user will be automatically taken to the result screen

Count
Count > Result

English admin Admin, ...

Save result data

Object Data

Dynamic object ID 878979	Dynamic object name 87679
Master object ID E656778	Master object name Eggs
ID number / Name 8767382 / Eggs	

Measurement Data

Reference weight 1.00 g / pcs	Result quantity 716 pcs	Net weight 0.7160 kg	Tare weight 0.0560 kg
Gross weight 0.7720 kg			

Device data

Used device
Internal code
KGP 6K 4
Model name
KGP 6K-4
Serial number
87897890

User information

Result generated by
Admin supervisor
on 2022-09-14 13:11:41

Company details not found!

☐ Auto print ☐ Update object in master memory

Back Print Export as PDF Save

4.2 Auto save full

- The purpose of auto save full is to save the result automatically without moving to the result screen every time once the measurement is done.
- The system will be automatically saving the result data in the dynamic database upon loading and unloading of the weight (until reaching zero) and stabilization of the object placed on the weighing scale.
- This might be useful in case if the operators in the industries are handling chemicals and might not be able to touch the application screen due to grease or other conditions.

Steps to be followed:

Step 1: Enable auto save full after defining the reference weight.

Count
Count

English admin Admin, ...

Internal code KGP 6K 4 Model name KGP 6K-4 Max 6 kg Min 0 d 0.0002 kg

713 pcs

Min: 0.0000 kg Max: 6.0000 kg

Tare 0.0000 kg Zero

Reference weight 1.00 g / pcs
Net weight 0.7126 kg


☐ Auto print

Auto save - Full


5x ref Weight = 5 pcs Define reference weight
10x ref Weight = 10 pcs Memory
20x ref Weight = 20 pcs Auto save - Semi
50x ref Weight = 50 pcs
100x ref Weight = 100 pcs Reset
Nx ref Weight = N pcs Result

Step 2: Place the objects that are required to be counted


Step 3: Wait until the weight on the scale is stabilized



Step 4: The system will automatically save the result in dynamic database.




The user can enable the auto print in case wanted to print the data automatically upon saving the data in dynamic database.



5. Result data

5.1 Measurement data

An overview of the determined data appears upon clicking on the button “result”. The below screen appears upon clicking the end button. The user might be able to view the complete result data. Here, the user might be able to



5.1.1 Add object from memory

The user might be able to pick an object from the memory where you can predefine list of objects what you use frequently. The object in the memory can be reutilized.

5.1.2 PDF, print and save

The user can save the data, generate the result data as an PDF or excel or print the results. All the saved results would be found in the dynamic database.

5.1.3 Dynamic object ID and name

The user can enter a reference id and name to the weighing objects to stay unique and search based on the dynamic id and name in the dynamic database (after the result data is being saved) regarding the weighing results of an object.

5.1.4 Update object in master memory

The user can be able to save the functional properties of the object in the master memory to reutilize the data by clicking on the “Update object in master memory”.

For example, the container weight and the reference weight will be updated in the master memory and can be utilized for future purposes.


5.1.5 Auto print

The user will have an option to save and print on a single click. This allows the user to print the data with the measurement ID.


Once the save button is clicked, the balance is again on weighing mode.

6. Dynamic data


- All the saved data would be found in the dynamic database. Click on the database icon and navigate to the dynamic database



- Click on the filter and the below screen would be displayed. Kindly note, the function weighing would be displayed by default.



- Choose the function count from the functions list and set the other desired filters and the required sort option



- The list of dynamic data saved against the set filter would be found here

Measurement ID	Master object ID	Dynamic object ID	Dynamic object name	Created on
Count-w14092022131933	E656778	784827	7832983	2022-09-14 13:19:33
Count-w14092022131819	-	-	-	2022-09-14 13:18:19
Count-w14092022131715	-	-	-	2022-09-14 13:17:15
Count-w14092022131201	E656778	878979	87679	2022-09-14 13:12:01

- Click on the required transactional data to see the complete set of details

Database

Databases > Reports list

English

admin

Admin, ...

Function

Count (4)

Search by

Count-w14092022131933

Measurement Data

Master object ID	Master object name	ID number / Name
E656778	Eggs	8767382 / Eggs
Dynamic object ID	Dynamic object name	Reference weight
784827	7832983	1.00 g / pcs
Result quantity	Net weight	Tare weight
535 pcs	0.5342 kg	0.0000 kg
Gross weight		
0.5342 kg		

Device data

Used device

Internal code

KGK 6K 4

Model name

KGK 6K-4

Serial number

87897890

User information

Result generated by

Admin supervisor

on 2022-09-14 13:19:33

Marlensoft, Tambaram, 600045, Chennai, India, 0889 98900 8798, marlensoft@gmail.com, www.marlensoft.com

Close

Export as PDF

Print

- The saved data can be printed, exported as PDF.

The end